


Strata Side Action Monobloc Kitchen Mixer



Size	Pattern No.	Pack 1 Qty	Pack 2 Qty	Code	Barcode	Price (£) ex VAT
NA	Side Action Monobloc Kitchen Mixer	1	4	4K6007	5022050239952	£120.17



0	Code	Description	Dimensions				
	4K6007		See image				
Pegler Yorkshire reserve the right to change specifications							

10 Year Guarantee Luxury Taps and Mixers

Pegler Yorkshire Customcare 10 Year Guarantee - Terms and Conditions

Product are subject to a 10 year guarantee that is between Pegler Yorkshire and the final purchaser of the product.

The guarantee is subject to proof of purchase being supplied.

This guarantee does not affect any statutory rights the consumer may have in law.

The guarantee covers manufacturing or material defects and does not cover parts subject to normal wear and tear.

Finishes other than chrome are covered for a period of 3 years only and the guarantee on the finish is subject to the cleaning instructions being followed.

The guarantee is not applicable where the product is fitted contrary to the conditions in the fitting instructions.

Abusive behaviour and accidental damage to the product are not covered by this guarantee.

The extent of this liability is limited to the cost of the replacement of the defective item and not to fitting or consequential damages.

Care

To maintain the surface finish, simply wipe occasionally with a mild detergent on a soft damp cloth. Dry, using a soft cloth. Never use abrasive cleaners or chemical household cleaners and avoid contact with

concentrated bleach.

Maintenance


No regular maintenance is required for this product.


In case of complete replacement Pegler recommend service valves should be fitted to the supply inlets.


For any further help or replacement parts please contact the Service Support Team on 0800 1560050.

Side Action Monobloc Kitchen Mixer

						1									
Spare Key	Spare Key Description		(Code Barcode		Э	Date From			Da	Date To		Price (£) ex VAT		
1	SPT36CP Spout A	ssemb	ly 8	854749 50220503498			034980	4	4 01/01/1900 To Cur				rrent £73.87		
						2									
Spare Key	Description		Code	de Ba		rcode		0	Date From		Date To		Price (£) ex VAT		
2	SK24 Head Seal	Kit	8545	80	502	5022050329578		01/01/1900		900	To Current		£5.25		
						3									
Spare Key	Description	Co	ode	Barcode D				Dat	Date From Date			-o	Pri	ice (£) ex VAT	
3	FL37CP Flange	85	4568	50	022050328694 01/01/1900 To Current				rrent	£13.20					
						4									
Spare Key	Description	(Code	Е	Barco	code I		Da	Date From		Date To		Price (£) ex VAT		
4	FP57 Fixing Pack	: 8	854512 5022050246615				615	01	/01/19	00	To Cı	urrent	ent £12.96		
						5									
Spare Key	Description			Code		Barcod	le		Date	From	n Date To		Price (£) ex VAT		
5	BN12 SUPPORT B	ACKN	UT	8544	63	501386	60849)4	01/0	1/1900	Тс	Curren	i i	£4.91	
						6									
Spare Key	Description	Code		Barco	rcode D		Date From		Da	Date To		Pric	Price (£) ex VAT		
6	H9 Head	8547	854754 5022050349903				01	01/01/1900 To Curre				ent £3.68			
						7									
Spare Key	Description		Code		Bar	code		Date From		om	Date To		Price (£) ex VAT		
7	AD11 Lever Adap	tor	8547	53	502	205034	9880	01/01/1900 To			To C	Current £15.75			
						8									
Spare Key	Description	Co	de	Bai	rcod	е	Da		Date From		Date To		Price (£) ex VAT		
8	B2 Lever Body	85	4751	502	2205	22050349842 01/01/1900 To Current £				£1:	5.75				
						9									
Spare Key	Description	Code		Barco	ode		Da		ate From		Date To		Price (£) ex VAT		
9	L83 Lever	8547	52	5022	0503	50349866 01			/01/1900 To			o Current £1		5.75	
						10									
Spare Key	Description			Code		Barcod	е		Date	From	Da	ite To	ı	Price (£) ex VAT	
10	HK101 Headwork (Cartrid	ge 8	85451	518 5022050247018 01/01/1900 To			Current	Current £46.88						
					1	1 not sh	nown								
Spare Key	Description								Price (£) ex VAT						
11 not shown	IT16 INLET TAIL (Flexible)	S PAII	R		854408 5013866080067 01/01/1900 To £23.69 Current										







Water Regulations Requirements

It is important to ensure that the water supplies to your taps and mixers are connected in accordance with the water regulations (WRAS) requirements and good plumbing practice.

It is Pegler's recommendation and good plumbing practice that the supplies of hot and cold water to the products should be at equal (balanced) pressures in order to provide a consistent flow. Supplies should be from a common source, either mains or tank fed. If supplies are not equal pressures then non return valves should be fitted (not supplied).

This products has been designed to function on all types of water systems

Please Note: If a pump is to be installed to boost gravity supplies please refer to the pump manufactures instructions.

The hot and cold inlets for any of the products are hot on the left and cold on the right when viewed from the front of the fitting. It is our recommendation and good plumbing practice that a service valve also (Pegler PB300) should be installed upstream in the inlet supply lines.

Pipe Connections

IMPORTANT. Before making any inlet pipe connections all supplies MUST be thoroughly flushed to remove any debris. Failure to do so could result in damage or low flow from the mixing valve. It is a requirement of Byelaw 55 of the Water Fittings Byelaw Scheme that this function is undertaken before making any pipe connections to supplies.

General Installation Notes

- Care must be taken during installation to prevent any risk of damage to the product or Injury to installer.
- Installation must be carried out by a qualified and competent person and in accordance with the instructions supplied.
- Installations must comply with all Local and National Water Authority Regulations, and Building/Plumbing Regulations.
- Please ensure that you have read and understood all sections of this manual before Installation.

Water Supply Pressures

Leger fittings have been designed to function under the following conditions:

- Minimum supply pressure 0.2 bar.
- Maximum supply pressure 6.0 bar.

Generous flow rates are achieved at pressures as low as 0.2 bar. At high pressures it may be necessary to reduce excessive flow rates by fitting stop or servicing valve in the supply line before the mixer or tap. These stop valves facilitate ease of maintenance should it be Necessary.

Please Note: The mono basin mixer L565 is supplied with flow straightener fitted and an alternative aerator nozzle packed separately which can be fitted at high pressures to reduce Splashing.

Installation

Mini Mono Basin / Mono Basin / Tall Mono Basin

- Screw flexible inlet tails into body and tighten up ensuring O ring seal is firmly in place and leak proof
- Locate and screw in place the securing/clamping studs
- iii) Locate seal under flange (or base of mono mixer) before placing fittings through hole in ware

 Please note: For tall mono basin, ensure the additional extension piece is located correctly to the main tap body

Please note: For fall mono basin, ensure the additional extension piece is located correctly to the main tap to liv.) Place clamping washer over securing/clamping studs and locate around inlet tails on the

- underside of the ware

 v) Place clamping plate on securing/clamping studs then place fixing nut onto the studs and tighten
- firmly up to the base of ware / worktop locating and aligning the fitting on top of the ware /i) Thoroughly flush pipework and connect tap to the supplies ensuring hot is on the left and cold on
- the right when viewing the mixer from the front.
- vii) Connect to the water supplies; ensure that the inlet tails seals are fitted correctly.
- viii) Turn on water supplied and check for leaks.
- ix) Insert click waste into hole in basin, ensuring a rubber seal is above and below the ware. A suitable bead of silicon can also be used to aid sealing of unit.
- x) Tighten in place using brass backnut before connecting to appropriate waste pipes.
- xi) Connect to water supply, turn on water supplies and check for leaks on tap and waste.

Wall Mounted Mono Basin / Mono Bath

 Make a suitable size hole in the wall or cavity. This should only be a big as the brass valve and not excessive.

Please note: offer the chromed wall plate up to the wall to ensure that there will be enough tiled wall all the way around the valve to sit the plate on later in the installation

Ii) Locate the body of the fitting in the cavity or hole ensuring its location is held in place with suitable clamps or straps and that the fitting is horizontal and level

Please note: the tap spout has to be on the left side of the installation for the fitting to be used the way it has been designed

- iii) Connect water suppliers so product can be checked before continuing with installation.
- Loosely locate handle on cartridge spindle and turn on water to ensure system if fully flushed of debris
- v) Remove handle
- vi) Cover the body of the fitting and cavity with the chromed wall plate, ensuring a suitable bead of silicon sealant is used to reduce the risk of wall getting in to the cavity from behind the wall plate
- vii) Re-locate the handle and tighten in place using screw under the lever.
- viii) Locate indice in hole under handle.
- ix) Push on chromed spout to the now exposed tubular outlet.
- x) Ensure chromed spout is located in place by tightening two screws on the underside.
- xi) Insert click waste into hole in basin, ensuring a rubber seal is above and below the ware. A suitable bead of silicon can also be used to aid sealing of unit.
- xii) Tighten in place using brass backnut before connecting to appropriate waste pipes.
- xiii) Connect to water supply, turn on water supplies and check for leaks on tap and waste

Mono Bath

- Screw copper inlet tails into body and tighten up ensuring O ring seal is firmly in place and leak proof
- ii) Locate and screw in place the securing/clamping studs
- iii) Locate seal under flange (or base of mono mixer) before placing fittings through hole in ware
- iv) Place clamping washer over securing/clamping studs and locate around inlet tails on the underside
 of the ware
- v) Place clamping plate on securing/clamping studs then place fixing nut onto the studs and tighten firmly up to the base of ware / worktop locating and aligning the fitting on top of the ware
- vi) Thoroughly flush pipework and connect tap to the supplies ensuring hot is on the left and cold on the right when viewing the mixer from the front.
- vii) Connect to the water supplies; ensure that the inlet tails seals are fitted correctly.
- viii) Connect to water supply, turn on water supplies and check for leaks on tap and waste.

Mono Sink Mixer

Screw flexible inlet tails into body and tighten up ensuring O ring seal is firmly in place and leak proof. Screw
in the clamping stud into the body and position rubber seal under the base of the mixer, position the mixer into the
ware in the desired position ensuring lever movement is not obstructed

Please note: Ensure free movement of spout is adequate before clamping in position

- $\label{thm:condition} In for oughly flush pipework and connect tap to the supplies ensuring hot is on the left and cold on the right when viewing the mixer from the front.$
 - iii) Connect to the water supplies; ensure that the inlet tails seals are fitted correctly
 - iv) Connect to water supply, turn on water supplies and check for leaks on tap and waste.

Care & Maintenance

To maintain the surface finishes, simply wipe occasionally with a mild detergent on a soft damp cloth. Dry using a soft cloth, never use abrasive cleansers or chemical household cleaners, and avoid contact with concentrated bleach. Pegler Yorkshire products are manufactured to the highest of standards and should require little or no maintenance. In the unlikely event of any spare part requirements, please visit our website: www.pegleryorkshire.co.uk or contact you're nearest stockist or the Pegler Yorkshire Sales Office, St Catherine's Avenue, Doncaster. DN4 8DF, telephone 0800 1560010, fax 0808 1561011 or the Pegler Yorkshire Technical Office on telephone 0800 1560050, fax 0808 1561012

Customer Reference Data

Date of Purchase
Supplier
Supplier Tel. No
Model Type
Installer
Installer Contact Details

Our brands:



















SOLAR SOLUTIONS









UK Sales

Free Phone: 0800 156 0010 Free Fax: 0808 156 1011

Email: uk.sales@pegleryorkshire.co.uk

Export

Tel: +44 (0) 1302 855 656 Fax: +44 (0) 1302 730 513 Email: export@pegleryorkshire.co.uk

Technical Help

Free Phone: 0800 156 0050 Free Fax: 0808 156 1012 Email: tech.help@pegleryorkshire.co.uk

Brochure Hotline

Free Phone: 0800 156 0020 Free Fax: 0808 156 1011 Email: info@pegleryorkshire.co.uk

www.pegleryorkshire.co.uk


Pegler Yorkshire Group Limited St. Catherine's Avenue, Doncaster,

South Yorkshire, DN4 8DF, England. Tel: 0844 243 4400 Fax: 0844 243 9870

Registered in England Company No. 00401507 Registered Office: Haigh Park Road, Stourton, Leeds, West Yorkshire, LS10 1RT, England.

All brand names and logo styles are registered trademarks. Maintaining a policy of continual product development, Pegler Yorkshire reserves the right to change specifications, design and materials of products listed in this publication without prior notice. Your Guide to the Installation, Care and maintenance of

Strata



K6002 Strata mini mono basin with click waste

4K6003 Strata tall mono basin with click waste

4K6004 Strata wall basin with click was te

4K6005 Strata mono bath

K6006 Strata wall bath

4K6007 Strata side action mono kitchen





Pegler Limited, St Catherine's Avenue, Doncaster DN4 8DF Telephone 01302 560560, Fax 01302 560109



This certifies that

PEGLER YORKSHIRE GROUP LTD.

has had the undermentioned product examined, tested and found, when correctly installed, to comply with the requirements of the United Kingdom Water Supply (Water Fittings) Regulations/Scottish Water Byelaws.

STRATA COMBINATION TAP ASSEMBLY

Reference should be made to the accompanying acceptance letter for installation requirements

The product so mentioned will be listed in the Water Fittings and Materials Directory for a period until:

02 NOVEMBER 2015

1011301

Certificate No.

Chairman, Test and Assessment Group

Secretary

WRAS APPROVED